



F/G:00






> GET Attp:/www.myserver.com/index. Atml Host: www. myserver.com HSH WHITE THE WASHINGTON THE WASHINGTON HOLD T HTTP/1.1 Host: WWW. myselver. com GET/index. Atmed HTTP/1.

F19.13

MAS receive session 141 request and other from MAS client determine propy(ies) and concatenation (S) determine PREP(A) to download from 144 determine PEE Server (si) to be used conduct dialogue (s)] with PEE Server (A)

FIG. 14

F19.15



PEE detects failure of neighbor PEE and reports to MAS MAS identifies replacement PEE installation disloque between MAS and replacement PEE Configuration dialogue 164 between MAS, replacement PEE and neighbor PEE

F19.16